Load-bearing capacity diagram

5065T (with cabin)



Service and spare

Are you looking for appropriate spare par
machine? With Kramer maintenance and r
part ready at hand for each machine. You
operating instruction from our Kramer deale
find your local dealer. Simply enter the sect

Maintenance, diagnosis and

The certified technician at your distributo
as quickly as possible. You can find mo
of Kramer machines on our website.

Original Spare Parts

All spare parts that you can source
requirements of our component manufa
fit and availability can largely only be pro

Warranty and safety

Security 24 / Security 36 / Security 48
to 24, 36, 48 or even 60 months, our c
They are protected against all eventu
Get advice from your dealer.